

NISSAN TIIDA SIDE MOULDING KIT

FITTING INSTRUCTIONS

PART NO: **KE960C11ML**

DESCRIPTION: **4-Piece Kit**

CONTENTS OF KIT: **4 x Moulded pieces**
1 x Fitting Instructions Sheet
2 x Cleaning Sachets

IMPORTANT

Thoroughly clean the area along the side of the vehicle where the Side Moulding Kit is going to be fitted. This area must be completely free of all traces of oil, grease, wax, polish, dirt, dust and moisture. Thoroughly dry the area.

Do not fit in temperatures below 55°F (13°C) as this affects the adhesion of the product.

If the temperature is below 55°F (13°C) you can warm the Side Moulding Kit up and the area where it is going to be stuck using a hair dryer or by fitting it in a warm garage.

Using the "Surface Cleaner" sachet provided, wipe around the area where the Side Moulding Kit is going to be fitted. The Surface Cleaner will prepare the bonding area so strong adhesion is achieved.

POSITIONING



This Side Moulding Kit is designed to be fitted according to the measurements given on the photo.

All distances are measured from the door bottom to the upper side of mouldings.

It is very important when fitting the front door moulding that an approximate gap of 2 - 3mm is left between the moulding and the door shut rear edge.

The rear door moulding should be positioned so it is in-line with the front door moulding and a gap of 2 - 3mm is left from the front edge of the rear door.

INSTALLING

Remove the protective tape from the adhesive, do not touch adhesive surface with your fingers. Fit the front door moulding first starting from the rear of the front door, applying pressure as you stick the mould into position.

Repeat same procedure for other moulding.

Rub Body Moulding Kit hard 3 or 4 times to ensure that a maximum bond is made. This adhesive takes time to cure so please do not wash car by hand within 3 days of instalation and do not put your vehicle through a car wash for 7 days.
